

FIBER OPTIC TRAINER

EXPERIMENT 3 SETTING UP FIBER OPTICAL LINK

Objective :

The objective of this experiment is to study a 650 nm fiber optic digital link. In this experiment you will study the relationship between the input signal and received signal.




Fig. 19 shows a simple drive circuit for binary digital transmission consisting a common emitter - saturating switch.

Procedure :

1. Connect the power supply to the board.
2. Ensure that all switched faults are in normal position.
3. Make the following connections (as shown in diagram 2).
 - a. Connect the FG 1KHz square wave output to emitters input.
 - b. Connect the 1 meter fiber optic cable between emitter output and detector input.
 - c. Detectors output to comparators input.
 - d. Comparators output to AC amplifier input.
4. On the board, switch emitter's driver to digital mode.
5. Switch ON the power.
6. Monitor both the inputs to comparator (TP9 & TP10). Slowly adjust the comparators bias pot, until DC Level on the input (TP9) lies midway between the high and low level of the signal on the positive input (TP11).

FIBER OPTIC TRAINER

Observed the input to emitter (TP5) with the output from AC amplifier (TP19) and note that the two signals are same.

